

## **FINISHING PROCEDURES FOR DOORLITE SURROUND/FRAME**

### **ELITE MF FRAME**

This frame does not require painting. This new plastic formulation will resist yellowing and deformation. If you choose to paint this frame, we recommend you follow these and the paint manufacturers recommendations for best results.

- 1) Thoroughly sand all plastic surfaces with a fine abrasive pad.
- 2) The surface should be wiped clean with a lint free cloth. The primer coat should be applied immediately. Apply a primer recommended for plastics, such as Zinsser Bulls Eye 1-2-3, for best results.
- 3) Apply an exterior acrylic latex topcoat.

### **ELITE TAN PC/ABS**

This frame comes ready for painting or staining. If painting, please apply an exterior acrylic latex topcoat. For staining, gel stains should be used for best results. Follow paint manufacturers directions when applying.

### **MCM PVC WHITE**

These extruded foam white PVC frames do not require finishing. If painting, a heat reflective paint is recommended. Follow paint manufacturers directions when applying.

### **NOTE: PAINT OR STAIN**

If you choose to use a solvent based stain, we strongly recommend that a cap bead of silicone be applied between the glass surface and between the frame and door surface. Application should be to exterior side only. Failure to do this may void warranty. An exterior grade top coat (finish coat) is recommended.

### **WARNING:**

Painting or staining a frame a dark colour or installing behind a storm door can cause heat damage not covered by warranty.

**IMPORTANT NOTE:  
WARRANTY WILL BE VOIDED IF PROCEDURES NOT ADHERED TO!**