

HOW TO INSTALL PATIO DOOR JAMB COVER



1. Install the top jamb pocket cover 3-4" far for the head, then slide the jamb cover up to ensure that the head end is tucked into the head-track.



2. Using a rubber mallet, tap the jamb cover into place, working your way from top to bottom.



3. See video of installation from start to finish:

<https://youtu.be/-5rg770-gOg>

HOW TO INSTALL THE SCREW COVER



Tap the sash screw end covers into place at the top and bottom of the operable sash, as pictured.

Note: Leave 2mm between the screw covers the tracks.